


Instruction Manual for working with Wall Prints



- Please read the instructions thoroughly before starting
- Assure that the surface you want to affix the Wall Decal to, is dry and free of dust and grease
- Mark the corners of the designated area using a pencil
- Place the Wall Print onto a smooth and even surface (e.g. table or floor) with the white backing paper on top, Wall Print facing down
- Carefully peel off approx. 4 inches of the backing paper starting on top of the Wall Print and Fold down the loose part of the backing paper
- Adjust your Wall Print using the pencil marks and carefully peel off the backing paper step by step, while smoothing out the Wall Print with a soft towel
- Smooth out the corners and edges of the Wall Print
- Note! Repeat the last step after 24 hours.

